

the intellitouch® PT20 TUNER


PT20 Operator's Manual

THE INTELLITOUCH® PT20 TUNER


We, at OnBoard Research, are dedicated to providing the best products and service in the industry. We thank you for the confidence you have placed in us by purchasing the Intellitouch® Tuner.

The Intellitouch® Tuner uses the latest in digital technology: a state of the art, low power digital signal processor, which “feels” the note of the instrument and displays it on a digital liquid crystal display for your easy reading.

THE INTELLITOUCH® PT20 TUNER PARTS AND FUNCTIONS



- 1) LCD Screen
- 2) Power/Function Button



- 3) Battery Compartment
- 4) Swivel to Adjust Viewing
- 5) Attachment Clamp

USING THE INTELLITOUCH® PT20 TUNER

To turn the tuner on or off, press and hold the Power/Function Button for 2 seconds. The tuner will automatically turn off after 2 minutes of inactivity.

Clamp the tuner securely to the instrument where the screen is easily visible. Pluck a string. The Display will show the note to which the string is tuned. The arrows on either side of the note letter indicate whether the note is flat, sharp or in tune. When all 6 arrows are displayed (3 on each side of the note letter) and the backlight turns green, the note is in tune. When more arrows appear on the left side of the note letter, the note is flat. When more arrows appear on the right side of the note letter, the note is sharp.



FLAT - More arrows on left and backlight glows red.



IN TUNE - All six arrows are displayed and backlight glows green.



SHARP - More arrows on right and backlight glows red.

CHANGING THE A-REFERENCE:

With the tuner on, double-press (2 quick presses) to enter the A-Reference Adjustment Mode. The frequency digits will blink. Single-press to scroll through the frequency references until the desired reference is reached, then simply stop and wait. After 3 seconds, the tuner will save the new reference and return to the tuning mode. A-Reference Range = 430-450Hz. The tuner defaults to A=440.

REPLACING THE BATTERY:

The Intellitouch® PT20 Tuner requires one CR2032 coin cell lithium battery. Slide the battery cover to remove or replace it. The battery should be placed positive side up.

Limited Lifetime Warranty. For warranty information visit our website at www.OnBoardResearch.com or call our customer service department at 800-340-8890.

Intellitouch® and OnBoard Research® are registered trademarks of OnBoard Research Corporation. The arrow display is copyrighted by OnBoard Research Corporation.

ONBOARD
RESEARCH
CORPORATION